

# How to connect Deye photovoltaic inverter to the Internet

How to install Deye Sun microinverter?

User manual DEYE SUN microinverter Installation procedure Step 1 - Installing the AC junction box a. Install a suitable junction box at a suitable location on the PV racking system (usually at the end of a module branch). b. Connect the open wire end of the AC cable to the junction box with a suitable gland or strain relief.

How do I install a dye Sun microinverter?

User manual DEYE SUN microinverter Installation of the micro inverter system A PV system with microinverters is easy to install. Each microinverter can be easily mounted on the PV frame directly under the PV module (s). The low voltage DC cables are connected directly from the PV module to the microinverter, avoiding the risk of high DC voltage.

How to install a PV system with microinverters?

A PV system with microinverters is easy to install. Each microinverter can be easily mounted on the PV frame directly under the PV module(s). The low voltage DC cables are connected directly from the PV module to the microinverter, avoiding the risk of high DC voltage.

How to install a microinverter with low voltage DC wires?

Low voltage DC wires connect from the PV module directly to the Microinverter, eliminating the risk of high DC voltage. Installation MUST comply with local regulations and technical rules. Installation Procedures Step 1 - Install the AC branch circuit junction box a.

How to activate Sta mode on Deye Sun microinverter?

Page 25 User Manual DEYE SUN Microinverter Connect to the AP network of the Microinverter, log in again at 10.10.100.254 and check the system information here. After the network settings are made, the STA mode of the wireless network is activated. The information about the...

Why does my Deye Sun microinverter Flash 4 times?

User manual DEYE SUN microinverter GFDI-Error A red LED flashing four times indicates that the micro inverter has detected a GFDI (Ground Fault Detector Interrupter) fault in the PV system. As long as the GFDI fault has not been rectified, the LED continues to flash four times.

Step 2 - Configure SolarAssistant to connect to a Deye/SunSynk/Sol-Ark. On the SolarAssistant configuration page, select "Deye, SunSynk, Sol-Ark" as your inverter model. Select the USB port where your inverter is connected. If you ...

Contact us for free full report

Web: <https://publishers-right.eu/contact-us/>

Email: [energystorage2000@gmail.com](mailto:energystorage2000@gmail.com)

WhatsApp: 8613816583346

