



Specifications of photovoltaic bracket anti-seismic base

What is a fixed adjustable photovoltaic support structure?

In order to respond to the national goal of "carbon neutralization" and make more rational and effective use of photovoltaic resources, combined with the actual photovoltaic substation project, a fixed adjustable photovoltaic support structure design is designed.

What is a seismic anchor & microinverter bracket?

Seismic Anchor: Secures the Ballast Tray directly to the building structure through roofing material and/or decking. Provides seismic lateral stability for module array. Microinverter Bracket: Attaches to Ballast Tray and secures microinverter. Works with Enphase, SolarEdge and DirectGrid microinverters.

What materials are used for mounting base brackets?

Mounting base brackets are fabricated from Series 6000 structural marine grade aluminum. 5/16" hardware included. "L" Feet are fabricated from high-strength 3/16" aluminum and include a vertical slot for adjusting to irregular surfaces. 5/16" coated hardware included. "L" Feet are fabricated from high-strength 3/16" aluminum.

How does ironridge seismic anchor work?

The IronRidge Seismic Anchor uses the EcoFasten Eco44R to attach to the roof structure and our customer bracket to securely attach to the Ballast Tray. Both the Seismic Anchor and Ballast Tray contain slots to accommodate for placement variances, up to +/- 4 inches of travel in every direction.

We have many years of experience in service and sales of seismic, photovoltaic bracket accessories, bridge accessories related products, the company's products sell well all over the country, including Zhenjiang Yangzhong, Wuhan, ...



Specifications of photovoltaic bracket anti-seismic base

Contact us for free full report

Web: <https://publishers-right.eu/contact-us/>

Email: energystorage2000@gmail.com

WhatsApp: 8613816583346

